
Cabled Vantage Pro2™ & Vantage Pro2 Plus™ Stations



The Vantage Pro2[™] (# 6152C) and Vantage Pro2[™] Plus (# 6162C) cabled weather stations include two components: the Integrated Sensor Suite (ISS) and the console. The ISS contains the sensor interface module (SIM), rain collector, an anemometer, and a passive radiation shield. The Vantage Pro2 console provides the user interface, data display, and calculations. The Vantage Pro2 Plus weather station includes two additional sensors that are optional on the Vantage Pro2 and purchased separately: the UV Sensor and the Solar Radiation Sensor. The console and ISS are powered by an AC-power adapter connected to the console. Batteries can be installed in the console to provide a backup power supply. Use WeatherLink[®] for Vantage Pro and Vantage Pro2 to let your weather station interface with a computer, log data, and upload weather information to the Internet. The 6152C and 6162C models rely on passive shielding to reduce solar-radiation induced temperature errors in the outside temperature sensor readings.

Integrated Sensor Suite (ISS)

Operating Temperature	-40° to +150°F (-40° to +65°C)
Non-operating Temperature	-40° to +158°F (-40° to +70°C)
Current Draw (ISS SIM only)	0.14 mA (average), 30 mA (peak) at 4 to 6 VDC
Solar Power Panel	0.5 Watts (ISS SIM), plus 0.75 Watts (Fan-Aspirated)
Battery (ISS SIM /Fan-Aspirated)	CR-123 3-Volt Lithium cell / 2 - 1.2 Volt NiCad C-cells
· · · · · · · · · · · · · · · · · · ·	8 months without sunlight - greater than 2 years depending on solar charging
Battery Life (NiCad C-cells)	1 year
Fan Aspiration Rate (Fan-Aspirated Only)	190 feet/min. (0.9 m/s) (full sun), 80 feet/min. (0.4 m/s) (battery only) (intake flow rate) 500 feet/min. (2.5 m/s) (full sun), 280 feet/min. (1.4 m/s) (battery only) (sensor chamber flow rate)
Connectors, Sensor	Modular RJ-11
Cable Type	4-conductor, 26 AWG
Cable Length, Anemometer	40' (12 m) (included) 540' (165 m) (maximum recommended)
Wind Speed Sensor	Wind cups with magnetic switch
Wind Direction Sensor	Wind vane with potentiometer
	Tipping bucket, 0.01" per tip (0.2 mm with metric rain adapter), 33.2 in 2 (214 $\text{cm}^2)$ collection area
Temperature Sensor Type	PN Junction Silicon Diode
Relative Humidity Sensor Type	Film capacitor element
Housing Material	UV-resistant ABS, ASA plastic
Sensor Inputs	
RF Filtering	RC low-pass filter on each signal line
ISS Dimensions:	

Product #	Dimensions (Length x Width x Height)	Package Weight
6152C	11.0" x 9.3" x 14.0" (279 mm x 238 mm x 355 mm)	5.7 lbs. (2.6 kg)
6162C		6.1 lbs. (2.8 kg)

Vantage Pro2[™]

Console

Console Operating Temperature	+32° to +140°F (0° to +60°C)
Non-Operating (Storage) Temperature	+14° to +158°F (-10° to +70°C)
Current Draw	0.9 mA average, 30 mA peak, (add 120 mA for display lamps, add 0.125 mA for each optional wireless transmitter received by the console) at 4 - 6 $$ VDC
AC Power Adapter	5 VDC, 300 mA, regulated
Battery Backup	3 C-cells
Battery Life (no AC power)	1 month (approximately)
Connectors	Modular RJ-11
Housing Material	UV-resistant ABS plastic
Console Display Type	LCD Transflective
Display Backlight	LEDs
Dimensions (console: length x width x height, display length	gth x height)
Console	9.63" x 6.125" x 1.625" (245 mm x 156 mm x 41 mm)
Display	5.94" x 3.375" (151 mm x 86 mm)
Weight (with batteries)	1.88 lbs. (.85 kg)

Data Displayed on Console

Data display categories are listed with General first, then in alphabetical order.

General

0110141	
Historical Graph Data	Includes the past 24 values listed unless otherwise noted; all can be cleared and all totals reset
Daily Data	Includes the earliest time of occurrence of highs and lows; period begins/ends at 12:00 am
Monthly Data	Period begins/ends at 12:00 am on the first of the month
Yearly Data	Period begins/ends at 12:00 am on the first of January unless otherwise noted
Current Display Data	Current display data describes the current reading for each weather variable. In most cases, the variable lists the most recently updated reading or calculation. Some current variable displays can be adjusted so there is an offset for the reading.
Current Graph Data	Current data appears in the right most column in the console graph and represents the latest value within the last period on the graph; totals can be set or reset. Display intervals vary. Examples include: Instant, 15-min., and Hourly Reading; Daily, Monthly, High and Low
Graph Time Interval	. 1 min., 10 min., 15 min., 1 hour, 1 day, 1 month, 1 year (user-selectable, availability depends upon variable selected)
Graph Time Span	. 24 Intervals + Current Interval (see Graph Intervals to determine time span)
Graph Variable Span (Vertical Scale)	. Automatic (varies depending upon data range); Maximum and Minimum value in range appear in ticker
Alarm Indication	Alarms sound for only 2 minutes (time alarm is always 1 minute) if operating on battery power. Alarm message is displayed in ticker as long as threshold is met or exceeded. Alarms can be silenced (but not cleared) by pressing the DONE key.
Update Interval	. Varies with sensor - see individual sensor specifications

Barometric Pressure

Resolution and Units	. 0.01" Hg, 0.1 mm Hg, 0.1 hPa/mb (user-selectable)
Range	. 16.00" to 32.50" Hg, 410 to 820 mm Hg, 540 to 1100 hPa/mb
Elevation Range	-999' to +15,000' (-600 m to 4570 m) (Note that console screen limits entry of lower elevation to -999' when using feet as elevation unit.)
Uncorrected Reading Accuracy	. ±0.03" Hg (±0.8 mm Hg, ±1.0 hPa/mb) (at room temperature)

Sea-Level Reduction Equation Used United States Method employed prior to use of current "R Factor" method Change 0.02" (.7hPa/mb, .5 mm Hg)= Slowly Trend Indication 5 position arrow: Rising (rapidly or slowly), Steady, or Falling (rapidly or slowly) Current Display Data Instant Alarms High Threshold from Current Trend for Storm Clearing (Rising Trend Low Threshold from Current Trend for Storm Warning (Falling Trend)

Clock

Range for Rising and Falling Trend Alarms 0.01 to 0.25" Hg (0.1 to 6.4 mm Hg, 0.1 to 8.5 hPa/mb)

Dewpoint (calculated)

nearest 1°C
Range ... -105° to +130°F (-76° to +54°C)
Accuracy ... ±3°F (±1.5°C) (typical)
Update Interval ... 10 to 12 seconds
Source ... World Meteorological Organization (WMO)
Equation Used ... WMO Equation with respect to saturation of moist air over water
Variables Used ... Instant Outside Temperature and Instant Outside Relative Humidity
Current Display Data ... Instant Calculation
Current Graph Data ... Instant Calculation; Daily, Monthly High and Low
Historical Graph Data ... Hourly Calculations; Daily, Monthly Highs and Lows
Alarms ... High and Low Threshold from Instant Calculation

Evapotranspiration (calculated, requires solar radiation sensor)

Resolution and Units	. 0.01" or 0.2 mm (user-selectable) $^{\circ}\text{C}$ is converted from $^{\circ}\text{F}$ rounded to nearest 1 $^{\circ}\text{C}$
Range	. Daily to 32.67" (832.2 mm); Monthly & Yearly to 199.99" (1999.9 mm)
Accuracy	. Greater of 0.01" (0.25 mm) or ±5%, Reference: side-by-side comparison against a CIMIS ET weather station
Update Interval	. 1 hour
Calculation and Source	. Modified Penman Equation as implemented by CIMIS (California Irrigation Management Information System) including Net Radiation calculation
Current Display Data	. Latest Hourly Total Calculation

Vantage Pro2[™]

Current Graph Data......Latest Hourly Total Calculation, Daily, Monthly, Yearly Total

Historical Graph Data Hourly, Daily, Monthly, Yearly Totals

Alarm High Threshold from Latest Daily Total Calculation

Forecast

Temperature, Humidity, Latitude & Longitude, Time of Year

and Speed

Heat Index (calculated)

nearest 1°C

 Accuracy
 ±3°F (±1.5°C) (typical)

 Update Interval
 10 to 12 seconds

Formulation Used Steadman (1979) modified by US NWS/NOAA and Davis Instruments

to increase range of use

Variables Used Instant Outside Temperature and Instant Outside Relative Humidity

Current Display Data Instant Calculation

Humidity

Inside Relative Humidity (sensor located in console)

Current Display Data Instant (user-adjustable offset available)

Outside Relative Humidity (sensor located in ISS)

 Drift
 ±0.5% per year

 Update Interval
 50 seconds to 1 minute

Current Display Data Instant (user-adjustable offset available)

Current Graph Data Instant and Hourly Reading; Daily, Monthly High and Low

Moon Phase

screen resolution)

Range New Moon, Waxing Crescent, First Quarter, Waxing Gibbous, Full

Moon, Waning Gibbous, Last Quarter, Waning Crescent

Rainfall

 Daily/Storm Rainfall Range
 0 to 99.99" (0 to 999.8 mm)

 Monthly/Yearly/Total Rainfall Range
 0 to 199.99" (0 to 9999 mm)

 Rain Rate
 0 to 96" (0 to 2438 mm)

Accuracy For rain rates up to 2"/hr (50 mm/hr): ±3% of total or +0.01" (0.25 mm)

(0.01" = one tip of the bucket), whichever is greater

For rain rates from 2"/hr (50 mm/hr) to 4"/hr (100 mm/hr): ±3% of total

or +0.01" (0.25 mm) (0.01" = one tip of the bucket), whichever is

greater

accumulation ends a storm event

Current Display Data Totals for Past 15-min

user-selectable) and Storm (with begin date); Umbrella is displayed

when 15-minute total exceeds zero

Historical Graph Data Totals for 15-min, Daily, Monthly, Yearly (start date user-selectable)

and Storm (with begin and end dates)

Alarms High Threshold from Latest Flash Flood (15-min. total, default is 0.50",

12.7 mm), 24-Hour Total, Storm Total,

Range for Rain Alarms 0 to 99.99" (0 to 999.7 mm)

Rain Rate

Calculation Method Measures time between successive tips of rain collector. Elapsed time

greater than 15 minutes or only one tip of the rain collector constitutes

a rain rate of zero.

Current Display Data Instant

Current Graph Data...... Instant and 1-min. Reading; Hourly, Daily, Monthly and Yearly High

Alarm High Threshold from Instant Reading

Solar Radiation (requires solar radiation sensor)

Drift. up to ±2% per year

Update Interval 50 seconds to 1 minute (5 minutes when dark)

Historical Graph Data Hourly Average, Daily, Monthly Highs

Alarm High Threshold from Instant Reading

Sunrise and Sunset

Vantage Pro2[™]

Temperature

Inside Temperature (sensor located in console)

converted from °F rounded to nearest 1°C

Historical Data and Alarms: 1°F or 1°C (user-selectable)

Current Display Data Instant (user-adjustable offset available)

Current Graph Data Instant Reading; Daily and Monthly High and Low Historical Graph Data...... Hourly Readings; Daily and Monthly Highs and Lows

Outside Temperature (sensor located in ISS)

(see Fig. 1) °C is converted from °F rounded to nearest 1°C

Historical Data and Alarms: 1°F or 1°C (user-selectable)

Fig. 2)

Radiation Induced Error (Passive Shield). +4°F (2°C) at solar noon (insolation = 1040 W/m², avg. wind speed ≤

2 mph (1 m/s)) (reference: RM Young Model 43408 Fan-Aspirated

Radiation Shield)

Radiation Induced Error (Fan-Aspirated Shield) +0.6°F (0.3°C) at solar noon (insolation = 1040 W/m², avg. wind

speed ≤ 2 mph (1 m/s)) (reference: RM Young Model 43408 Fan-

Aspirated Radiation Shield)

Current Display Data Instant (user-adjustable offset available) Current Graph Data Instant; Daily, Monthly, Yearly High and Low

Historical Graph Data..... Hourly Readings; Daily, Monthly, Yearly Highs and Lows

Alarms High and Low Thresholds from Instant Reading

Temperature Humidity Sun Wind Index (requires solar radiation sensor)

nearest 1°C

Sources and Formulation Used United States National Weather Service (NWS)/NOAA

Steadman (1979) modified by US NWS/NOAA and Davis Instruments

to increase range of use and allow for cold weather use

Variables Used Instant Outside Temperature, Instant Outside Relative Humidity, 10-

minute Average Wind Speed, 10-minute Average Solar Radiation

radiation are either added or subtracted from this base to give an

overall effective temperature

Current Graph Data...... Instant and Hourly Calculation; Daily, Monthly High

Historical Graph Data Hourly Calculation; Daily, Monthly Highs Alarm High Threshold from Instant Reading

Ultra Violet (UV) Radiation Dose (requires UV sensor)

Drift.....up to ±2% per year

Update Interval 50 seconds to 1 minute (5 minutes when dark)

Current Graph Data..... Latest Daily Total (user resetable at any time from Current Screen)

Historical Graph Data Hourly, Daily Totals (user reset from Current Screen does not affect

these values)

Alarm High Threshold from Daily Total Alarm Range 0 to 19.9 MEDs

Ultra Violet (UV) Radiation Index (requires UV sensor)

High))

Update Interval 50 seconds to 1 minute (5 minutes when dark)

Current Graph Data...... Instant Reading and Hourly Average; Daily, Monthly High

Wind

Wind Chill (Calculated)

 Accuracy
 ±2°F (±1°C) (typical)

 Update Interval
 10 to 12 seconds

Variables Used Instant Outside Temperature and 10-min. Avg. Wind Speed

Current Display Data Instant Calculation

Current Graph Data Instant Calculation; Hourly, Daily and Monthly Low

Wind Direction

Update Interval 2.5 to 3 seconds

Current Graph Data Instant Reading (user adjustable); 10-min. Dominant; Hourly, Daily,

Monthly Dominant

Historical Graph Data. Past 6 10-min. Dominants on compass rose only; Hourly, Daily,

Monthly Dominants

Wind Speed

other units are converted from mph and rounded to nearest 1 km/hr, 0.1

m/s, or 1 knot.

Update Interval Instant Reading: 2.5 to 3 seconds, 10-minute Average: 1 minute

length of cable from anemometer to ISS increases.)

Current Display Data Instant

Current Graph Data Instant Reading; 10-minute and Hourly Average; Hourly High; Daily,

Monthly and Yearly High with Direction of High

Highs with Direction of Highs

Sensor Charts




Figure 1. Temperature Resolution




Figure 3. Low Range Rain Rate Resolution




Figure 2. Temperature Accuracy




Figure 4. Full Range Rain Rate Resolution

Package Dimensions

Product #	Package Dimensions (Length x Width x Height)	Package Weight	UPC Codes
6152C	17.0" x 11.0" x 13.0" (410 mm X 264 mm x 330 mm)		011698 00755 4
6152CEU		12.8 lbs. (5.8 kg)	011698 00772 1
6152CUK			011698 00773 8
6162C			011698 00756 1
6162CEU		13.3 lbs. (6.0 kg)	011698 00774 5
6162CUK			011698 00775 2